

AD-A026 846

RIA-76-U387

USADACS Technical Library



5 0712 01002991 5

AFB
BH
TECHNICAL
LIBRARY

AD-A026 846

COPY NO. 3

TECHNICAL MEMORANDUM 2203

AUTOMATIC X-RAY NEGATIVE ANALYSIS
PROGRAM (AXNAP)

EDWARD H. JOSEPHS

JUNE 1976

APPROVED FOR PUBLIC RELEASE. DISTRIBUTION UNLIMITED.

PICATINNY ARSENAL
DOVER, NEW JERSEY



The findings in this report are not to be construed as an official Department of the Army position.

DISPOSITION

Destroy this report when no longer needed. Do not return to the originator.

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

REPORT DOCUMENTATION PAGE		READ INSTRUCTIONS BEFORE COMPLETING FORM
1. REPORT NUMBER Technical Memorandum 2203	2. GOVT ACCESSION NO.	3. RECIPIENT'S CATALOG NUMBER
4. TITLE (and Subtitle) AUTOMATIC X-RAY NEGATIVE ANALYSIS PROGRAM (AXNAP)		5. TYPE OF REPORT & PERIOD COVERED
		6. PERFORMING ORG. REPORT NUMBER
7. AUTHOR(s) Edward H. Josephs		8. CONTRACT OR GRANT NUMBER(s)
9. PERFORMING ORGANIZATION NAME AND ADDRESS Product Assurance Directorate Picatinny Arsenal Dover, NJ 07801		10. PROGRAM ELEMENT, PROJECT, TASK AREA & WORK UNIT NUMBERS
11. CONTROLLING OFFICE NAME AND ADDRESS		12. REPORT DATE June 1976
		13. NUMBER OF PAGES 18
		15. SECURITY CLASS. (of this report) Unclassified
14. MONITORING AGENCY NAME & ADDRESS (if different from Controlling Office)		15a. DECLASSIFICATION/DOWNGRADING SCHEDULE
16. DISTRIBUTION STATEMENT (of this Report) Approved for public release, distribution unlimited.		
17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if different from Report)		
18. SUPPLEMENTARY NOTES		
19. KEY WORDS (Continue on reverse side if necessary and identify by block number) Shell defects X-ray Graphics Tektronix terminal		
20. ABSTRACT (Continue on reverse side if necessary and identify by block number) The Automatic X-Ray Negative Analysis Program (AXNAP) is a computer software program developed for use on Control Data Corporation's Computer No. 6600 interfaced with Tektronix Terminal No. 4014/15 enhanced graphics module. Accompanying this hardware is Tektronix Tablet No. 4954 which has the capability of translating tablet coordinate data into digital positions on the terminal screen with an accompanying transfer to a CDC 6600 buffer. A hard-copy unit is also part of the hardware.		

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE(When Data Entered)


20. ABSTRACT (Continued)

AXNAP is an improved concept of x-ray data analysis which provides accurate data more quickly than other methods and does not require specially trained technicians.

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE(When Data Entered)

The citation in this report of the names of commercial firms or commercially available products or services does not constitute official endorsement or approval of such commercial firms, products, or services by the United States Government.



ACKNOWLEDGMENT

The author wishes to thank Mr. Joel Glaser of the Product Assurance Directorate, Picatinny Arsenal, for his assistance in helping to coordinate this project.





TABLE OF CONTENTS

	Page No.
Introduction	1
Development	1
Operating Procedure	2
Preliminary Instructions	2
Sample Output	4
Distribution List	11
Table 1 Sample output	5
Figures	
1 AXNAP menu	7
2 Vertical orientation of 105 mm shell	8
3 AXNAP components	9
4 AXNAP components in use	10



INTRODUCTION

In the present method of x-ray data analysis, the data is read by an x-ray technician trained in using a line grid. The area of the defect is determined by counting grid squares; the width, by counting the number of grid spaces between two end points; and the height, by counting the grid spaces from the base of the shell. Once this information is obtained, it is recorded and punched on cards. In addition to requiring specially trained personnel, the procedure is tedious, time consuming, and subject to inaccuracies.

The Automatic X-Ray Negative Analysis Program (AXNAP) is an improved concept of x-ray data analysis. It provides the same information as the method described above, but does so more quickly and accurately, and does not require a specially trained technician. The operator need only follow a menu using a digitized pen for entering shell data. All information is compiled in report form automatically, eliminating the necessity of recording data and punching cards. As a result, the area calculations, end points, etc., are more accurate than those determined by the grid method.

DEVELOPMENT

A menu was developed which allows the operator to process x-rays without any knowledge of the computer hardware involved. This menu (Fig 1) enables the technician to input shell data without using the Tektronix keyboard.

The menu is placed on the tablet in any position and is oriented by the operator's entering points one and two, as shown in Figure 1. The x-ray may also be placed in any position on the tablet. The shell shown on the x-ray is oriented with respect to the menu by the operator's entering one point on the annular ring and a second point on the distal end of the shell (see Fig 2). The final results of the defect data analysis are referenced to the base of the shell. For area calculations of a particular defect, the operator enters as many points as desired in a single-point mode. Continuous mode operation for tracing areas will be incorporated into AXNAP when a buffer is added to the CDC hardware.

AXNAP provides many checks and rechecks for detecting operating errors. Operators are allowed to re-enter input data at various points in the program (see Operating Procedure, below). As the shell defect data is processed, the results are displayed on the Tektronix terminal screen, which will accommodate a maximum of 32 lines of data. The operator also has the option of using less than 32 lines and starting a new page if desired. In each case, a hard copy of the page is generated as it is completed. In addition, a line print of the total output can be retrieved after the last shell is analyzed.

The components of the system are shown in Figures 3 and 4.

OPERATING PROCEDURE

Preliminary Instructions

1. Gain access to the CDC 6600 central processor by using the Tektronix terminal interface.
2. Attach the file on which AXNAP is located.
3. Orient the menu by following the instructions displayed on the Tektronix screen.

Shell Processing (Refer to menu, Figure 1)

1. Enter one point in Blocks I, II, and III, then strike "Continue."
2. Omit Block IV (to speed up operation).
3. Enter shell, group, and lot numbers as the first three entries in Block V, using a maximum of 11 points each. Check the Tektronix display screen to verify accuracy of the input data. If data is correct, strike "Continue;" if not, correct error by striking "Error Re-enter" and entering correct data in appropriate

sub-block before striking "Continue."¹ ("Continue" must be struck before shell is oriented.)

4. Orient the shell (as shown on the x-ray) by placing the pen on the point 1 (the annular ring) and striking "Continue," then on point 2 (the distal end) and striking "Continue." This orients the shell with respect to the menu; however, the shell can be positioned either vertically or horizontally, as the operator chooses.

5. Select the defects to be analyzed and enter points in Block VI as follows:

a. For the first three defects in Block VI (cavity, piping cavity, and porous area), enter two end points, then strike "Continue." Trace the area over each of the three defects to permit the low point to be calculated by AXNAP.

b. For the next three defects (annular ring, base separation, and crack), enter the low points and strike "Continue." Use Block VII to approximate the width of the defect.

c. For the remaining six defects, simply enter the lowest point on the defect and strike "Continue."

d. Use "New Page" to generate a hard copy of the existing page and begin a new one, as desired.

6. After the defects for one shell have been analyzed, move on to the next. If it is a new type of shell, enter all of the required information, starting with Block I. If it is the same type as the previous shell, start with Block V. Use the "Same" block to indicate that the preceding shell number, group number, or lot number is being re-entered. Use the "Next" block to increment the shell number by adding "1." (This saves the time required to enter a new shell number.)

7. Orient the shell as indicated in Step 4, above, before entering points in Block VI.

¹At any point that the operator is aware of entering the wrong block, he can correct the error by striking "Error Re-enter" and entering the correct block. If he hits the correct block but the transmission is incomplete because of heavy usage of the system, a bell will ring. In this case, it is not necessary to strike "Error Re-enter" before re-entering the correct block.

8. In Block VI, enter "New Shell Type" or "Small Shell Type," as appropriate, and continue entries, as described in Step 5, above.

Sample Output

Table 1, which shows the defect analysis of a 105 mm shell, is typical of AXNAP's output.

Note that the "Total Def" column is cumulative for each defect analyzed. The low point and end points 1 and 2 for each defect are given in coordinates referenced to the base of the shell.

Table 1

Sample output

PROJECTILE-105MM M1 SHELL NO. 012346789		AMATEX X-RAY FILM READING(DEC,1975) GROUP NO. AB				PAGE- 1		LOT NO.	KL-N/T	
TOTAL DEF	DEF TYPE	LOW POINT		END POINT		END POINT		WIDTH	AREA	
-1.5856				1		2				
1.	01 CAVITY	-0.550	5.780	-1	.556	5.824	-0.598	5.834	.9582	1.0093
1.	02 PIP CAU	-0.550	14.966		.820	4.999	3.271	7.373	3.4117	3.1175
3	03POROSITY	-0.550	6.826	-1	.172	6.798	-0.556	6.826	.6169	.1394
1.	04 ANNIRING	-1.15	5.84						1/8 LT 1/4	
2.	04 ANNIRING	1.97	3.62						GT 3/8	
3.	04 ANNIRING	2.24	7.42						1/4 LT 3/8	
1.	05 BASESEP	1.91	5.64						LT1/64	
2.	05 BASESEP	2.11	9.12						1/64LT1/32	
3.	05 BASESEP	.23	7.23						1/32LT1/16	
4.	05 BASESEP	-2.03	10.49						GT 1/16	
1.	06CRACK	.89	8.63						GT1/8	
2.	06CRACK	.47	5.85						LT 1/32	
1.	20 FOR MAT	.86	3.16							

NOTE: The spacing in the fourth column (END POINT 1) is wrong due to computer error. The first and third entries should read "-1.556" and "-1.172."

Table 1 (Continued)

PROJECTILE-105MM M1			AMATEX X-RAY			FILM READING(DEC,1975)			PAGE- 2		LOT NO.	KL-M/T
SHELL NO. 01 2346789			GROUP NO. AB									
TOTAL	DEF	DEF TYPE	LOW POINT		END POINT		1	END POINT		2	WIDTH	AREA
1.		31 METIREG	.73	5.11								
1.		MET DEF	-.89	5.58								
1.		41 PEL CRK	-.89	6.23								
1.		42 PEL MIS	-2.16	7.48								
2.		31 METIREG	-.97	5.73								
2.		20 FOR MAT	1.94	4.30								
1.		43 PEL BRK	2.00	2.82								
4.		04 ANN RING	1.21	4.40							LT 1/8	
2.		02 PIP CAU	-1.552	5.813	-1	.561 5.870		-.586	5.854		.9752	.0014
3.		06CRACK	.22	5.03							GT1/8	
2.		03POROSITY	-1.552	5.828	-1	.516 4.764		-.585	4.816		.9316	.3677
3.		31 METIREG	.55	3.89								
2.		41 PEL CRK	.60	5.95								

NOTE: Entries in the fourth column (END POINT 1) should read "-1.561" and "-1.516."

BLOCK I	105 MM	155 MM	8 INCH													
BLOCK II	JAN	FEB	MAR	APR	MAY	JUN										
	JUL	AUG	SEP	OCT	NOV	DEC										
BLOCK III	1975	1976	1977	1978												
BLOCK IV	SHELL NO.	GROUP NO.	LOT NO.													
BLOCK V	0	1	2	3	4	5	6	7	8	9		SAME				
	A	B	C	D	E	F	G	H	I	J						
	K	L	M	N	O	P	Q	R	S	T		NEXT				
	U	V	W	X	Y	Z		-	/	*						
								I	II	III	IV					
BLOCK VI	CAVITY	PIPING CAVITY	POROUS AREA		NEW TYPE SHELL	NEW PAGE		SAME TYPE SHELL								
	ANNULAR RING	BASE SEPARAT	CRACK	FINISH												
	FOREIGN MATL	METAL IRREG	METAL DEFECT													
	PELLEY CRACKED	PELLEY MISSING	PELLEY BROKEN													
	BLOCK VII	$< \frac{1}{32}$	$\frac{1}{32} < \frac{1}{16}$	$\frac{1}{16} < \frac{1}{8}$	$> \frac{1}{8}$	CRACK										
$< \frac{1}{8}$		$\frac{1}{8} < \frac{1}{4}$	$\frac{1}{4} < \frac{3}{8}$	$> \frac{3}{8}$	ANNULAR RING											
$< \frac{1}{64}$		$\frac{1}{64} < \frac{1}{32}$	$\frac{1}{32} < \frac{1}{16}$	$> \frac{1}{16}$	BASE SEPARATION											

ERROR RE-ENTER

CONTINUE

①

②

Fig 1 AXNAP menu

VERSION 1 11/1975
E. JOSEPHS
PRODUCT ASSURANCE DIRECTORATE
PICATINNY ARSENAL
DOVER NEW JERSEY

105MM M1




Fig 2 Vertical orientation of 105 mm shell



F1g 3 AXNAP components




Fig 4 AXNAP components in use


DISTRIBUTION LIST

Copy No.

Commander U.S. Army Materiel Development and Readiness Command ATTN: DRCQA 5001 Eisenhower Avenue Alexandria, VA 22304	1
Commander U.S. Army Armament Command ATTN: DRSAR-QA DRSAR-ASF Rock Island, IL 61201	2 3
Project Manager for Nuclear Munitions U.S. Army Materiel Development and Readiness Command ATTN: DRCPM-NUC Dover, NJ 07801	4
Chief U.S. Army Nuclear and Chemical Surety Group ATTN: MDSG-ND Building 2073 North Area Fort Belvoir, VA 22060	5
Commander Watervliet Arsenal ATTN: SARWV-QA Watervliet, NY 12189	6
Commander U.S. Army Aberdeen Research and Development Center ATTN: Mr. R. Eisner Aberdeen Proving Ground, MD 21005	7
Director Weapons System Evaluation Group 400 Army Navy Drive Arlington, VA 22202	8

<p>Commander Harry Diamond Laboratories 2800 Powder Mill Road ATTN: DRXDO-EDE, Mr. R. Niemeyer Adelphi, MD 20783</p>	9
<p>U.S. Energy Research and Development Administration Albuquerque Operations Office ATTN: Mr. G. A. Hauquitz P.O. Box 5400 Albuquerque, NM 87115</p>	10
<p>Sandia Laboratories ATTN: Mr. William Gordon 8367 Livermore, CA 94550</p>	11
<p>Sandia Corporation ATTN: Mr. William Dennison 9520 Albuquerque, NM 87115</p>	12
<p>Kelly Air Force Base ATTN: SAAMA/MMEW-4, Mr. Bernard W. Boisvert Kelly Air Force Base, TX 78241</p>	13
<p>U.S. Army Materials and Mechanics Research Center ATTN: DRXMR-Q, Mr. Fahey Watertown, MA 02172</p>	14
<p>Naval Weapons Station Radiographic and Propulsion Branch Quality Evaluation and Engineering Laboratory ATTN: Mr. Brunty Code 33210 Concord, CA 94520</p>	15
<p>Wright-Patterson Air Force Base ATTN: AFML/MXA, Mr. Edward W. McKelvey Wright-Patterson Air Force Base, OH 45433</p>	16
<p>U.S. Navy Surface Weapons Center White Oak Laboratory ATTN: Mr. Daniel Polansky Silver Spring, MD 20910</p>	17

Commander Frankford Arsenal ATTN: SARFA-QAA-Q, Mr. John G. Barr Bridge and Tacony Streets Philadelphia, PA 19137	18
National Bureau of Standards Institute for Materials Research ATTN: Mr. Harold Berger Washington, DC 20234	19
Commander Defense Documentation Center Cameron Station Alexandria, VA 22314	20-31
Commander Picatinny Arsenal ATTN: SARPA-TS-S	32-36
SARPA-AD	37
SARPA-MI	38
SARPA-ND	39
SARPA-QA	40
SARPA-QA-A	41
SARPA-QA-T	42
SARPA-QA-T-C	43
SARPA-QA-T-T	44
SARPA-QA-N	45-54
Dover, NJ 07801	



The first of these is the fact that the
 government has been unable to
 maintain a stable currency. This
 has led to a loss of confidence
 in the government and a
 consequent loss of support
 from the people. The second
 is the fact that the government
 has been unable to maintain
 a stable economy. This has
 led to a loss of confidence
 in the government and a
 consequent loss of support
 from the people. The third
 is the fact that the government
 has been unable to maintain
 a stable society. This has
 led to a loss of confidence
 in the government and a
 consequent loss of support
 from the people.

The fourth is the fact that the
 government has been unable to
 maintain a stable foreign
 policy. This has led to a
 loss of confidence in the
 government and a consequent
 loss of support from the
 people.